## 8.0 Lesson - Core Location

Paul Solt - Paul@SuperEasyApps.com SuperEasyApps.com

• 8.0 Lesson - Core Location

#### 8.1 Lecture - Core Location

In this lesson you will learn how to get started with core location and user privacy permissions.

#### 8.2 Tutorial - Core Location Setup

To enable locations for your app you'll need special settings and permission from the user.

1. Add .plist settings for messages that will display to the user if you need their location.



NSLocationAlwaysUsageDescription NSLocationWhenInUseUsageDescription

#### with the message:

Your location is required to fetch the weather automatically.

2. In ViewController.swift import the Core Location module

import CoreLocation

3. Add a cityLabel outlet

@IBOutlet weak var cityLabel: UILabel!

4. Create the locationManager, set the delegate, and request weather data

```
let locationManager = CLLocationManager()
override func viewDidLoad() {
    super.viewDidLoad()

// requestWeather()
    updateDate()
    clearWeather()

    locationManager.delegate = self
    locationManager.desiredAccuracy = kCLLocationAccuracyBest
    locationManager.requestWhenInUseAuthorization()
    locationManager.startUpdatingLocation()
}
```

5. Conform to the CLLocationManagerDelegate protocol

```
class ViewController: UIViewController, CLLocationManagerDelegate {
```

Update the requestWeather() method to take a location. Comment out the old request in viewDidLoad()

```
func requestWeather(location: CLLocationCoordinate2D) {
    // construct URL

let weatherURL = NSURL(string: "\(weatherAPI)/\(apiKey)/\(location.latitude),\(location.longitude)") // US units (miles, F)
```

Implement the location delegate methods

# 8.3 Tutorial - Request Location Placemarks Using CLGeocoder

SuperEasyApps.com 2/7

1. Update the locationManager(\_: didUpdateLocations:) method

```
func locationManager(manager: CLLocationManager, didUpdateLocations locations: [CLLocation]) {
   print("locationManager didUpdateLocation")
   // Most recent location is at end of array
   if let location = locations.last {
        updateCityUsingLocation(location)
        requestWeather(location.coordinate)
   }
   // stop updating location, Geocoder is rate limited (so is weather API!)
   manager.stopUpdatingLocation()
}
```

2. Implement the updateCityUsingLocation(\_:) method using CLGeocoder

```
func updateCityUsingLocation(location: CLLocation) {
   let geoCoder = CLGeocoder()
   geoCoder.reverseGeocodeLocation(location, completionHandler: { (placemarks: [CLPlacemark]?, error:
NSError?) -> Void in
        if let placemark = placemarks?.first {
            if let locality = placemark.locality {
                // update the city
                print("City:", locality)
                self.cityLabel.text = locality
            }
        }
        if let error = error {
            print("Error requesting Geocoding requests:", error)
        }
   })
}
```

## 8.4 Tutorial - Requesting User Permission Refined

1. Stop requesting location by commenting out the requestWhenInUseAuthorization() and startUpdatingLocation() methods

```
override func viewDidLoad() {
    super.viewDidLoad()
    updateDate()
    clearWeather()

    locationManager.delegate = self
    locationManager.desiredAccuracy = kCLLocationAccuracyBest

// locationManager.requestWhenInUseAuthorization()

// locationManager.startUpdatingLocation()
}
```

2. Override viewDidAppear(:) to request permission to get the user's location

SuperEasyApps.com 3/7

```
override func viewDidAppear(animated: Bool) {
    super.viewDidAppear(animated)
    requestLocationAccess()
}
```

Implement the new method to request location permission

```
func requestLocationAccess() {
   print("Request location")
   switch CLLocationManager.authorizationStatus() {
   case .AuthorizedAlways:
       fallthrough
   case .AuthorizedWhenInUse:
       // ...
       print("Location Enabled")
       locationManager.startUpdatingLocation()
   case .NotDetermined:
        // First time using app, the user needs to provide permission
        print("Request location access")
        locationManager.requestWhenInUseAuthorization()
//
                        locationManager.requestAlwaysAuthorization()
   case .Restricted, .Denied:
       print("Location access disabled")
        showLocationDeniedPopup()
    }
}
func showLocationDeniedPopup() {
    // TODO: implement popup logic to the settings app
}
```

4. Implement the showLocationDeniedPopup() method to have the user change their privacy permissions

```
func showLocationDeniedPopup() {
   let alertController = UIAlertController(
       title: "Background Location Access Disabled",
       message: "In order to fetch the weather, please open this app's settings and allow location
access.",
       preferredStyle: .Alert)
   let cancelAction = UIAlertAction(title: "Cancel", style: .Cancel, handler: nil)
   alertController.addAction(cancelAction)
   let openAction = UIAlertAction(title: "Open Settings", style: .Default) { (action) in
        // Use dispatch asynch to fix bug when returning from settings app
        dispatch async(dispatch get main queue(), {
            if let url = NSURL(string:UIApplicationOpenSettingsURLString) {
                UIApplication.sharedApplication().openURL(url)
            }
       })
   alertController.addAction(openAction)
   self.presentViewController(alertController, animated: true, completion: nil)
}
```

SuperEasyApps.com 4/7

5. If the user gives your app permission after saying denying, you might not get location updates. Add the code to enable location data if privacy changes.

### 8.5 Tutorial - Testing Core Location Permissions

Note: The simulator can be a bit buggy/delayed with location data and simulation. It is best to test on a real device. There are sometimes location requests that happen after a 5–7 second delay when starting the app or after making a request.

- 1. Cleanup output print statements (ViewController json parsing and WeatherDataPoint)
- 2. Test the app and see if it creates duplicate weather requests
- 3. Add a refresh button to the top left corner, connect an action, and implement logic to request weather

```
@IBAction func refreshButtonPressed(sender: AnyObject) {
    print("refresh")
    locationManager.startUpdatingLocation()
}
```

4. Prevent duplicate weather requests with isFetchingWeather Bool variable

```
var isFetchingWeather = false

func locationManager(manager: CLLocationManager, didUpdateLocations locations: [CLLocation]) {
   print("location didUpdateLocation:", locations)

if !isFetchingWeather {
    isFetchingWeather = true
    if let location = locations.last {
        // update the city
        updateCityUsingLocation(location)
        // request the weather
            requestWeather(location.coordinate)
     }
}

// Stop updating (API usage = $ and Geocoding has API ratelimits)
```

SuperEasyApps.com 5/7

```
locationManager.stopUpdatingLocation()
}
```

- 5. Set a location and test the daily Forecast ... do see the bug with the weather request logic?
- 6. Remove viewDidAppear(\_:) method and move the request to the viewDidLoad() method using performSelector after delay.

```
override func viewDidLoad() {
    super.viewDidLoad()

    updateDate()
    clearWeather()

    locationManager.delegate = self
    locationManager.desiredAccuracy = kCLLocationAccuracyBest

    performSelector(#selector(requestLocationAccess), withObject: nil, afterDelay: 0.01)
}
```

#### 8.6 Tutorial - Testing Core Location on a Real iPhone

Try out your app on your real iPhone and in different locations!

#### Links

- Location and Maps Programming Guide
- CLLocationManager

## 8.7 Tutorial - Getting Started With Map Kit

1. Import the MapKit module

```
import MapKit
```

Add code to display a map

```
var mapView: MKMapView!
override func viewDidLoad() {
    // ...
    performSelector(#selector(requestLocationAccess), withObject: nil, afterDelay: 0.01)
    mapView = MKMapView(frame: self.view.frame)
    view.addSubview(mapView)
    mapView.hidden = true
}
```

SuperEasyApps.com 6/7

- 2. Create a button in the menu bar called Map along with an action method
- 3. Show and hide the map when the button is pressed by toggling the hidden property

```
@IBAction func mapButtonPressed(sender: AnyObject) {
   mapView.setUserTrackingMode(.Follow, animated: true)
   mapView.showsUserLocation = true

   mapView.hidden = !mapView.hidden
}
```

4. Refresh the location when the refresh button is pressed

```
@IBAction func refreshButtonPressed(sender: AnyObject) {
    print("refresh pressed")
    locationManager.startUpdatingLocation()
    mapView.setUserTrackingMode(.Follow, animated: true)
}
```

#### Links

Maps and MapKit

SuperEasyApps.com 7/7